



Asus Zenbook UX31E Battery Replacement

A guide on replacing the battery in a Asus Zenbook UX31E

Written By: Hersi Dahir






TOOLS:

- [iFixit Opening Tools](#) (1)
 - [T4 Torx Screwdriver](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Back Cover





- Using a T4 Torx Screwdriver, unscrew the screws at the marked locations.
- ⓘ Place the screws into a container as to not lose them.

Step 2





- Using your iFixit Opening Tool, carefully slide it between the back panel.
- Lift the back plate of your ASUS ZenBook UX31E and place it to the side.

Step 3 — Battery





- Disconnect the battery from the motherboard by gently pulling up and down on the connector.

Step 4



- Using the Phillips 00 Screwdriver, remove the screw from the middle and the two corners of the battery.
- ⓘ Place the screw into a container as to not lose them.

Step 5



- Remove the battery

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-06 08:19:01 AM.